



Epson ELPDC05 High Resolution Document Imager

For further assistance, call the HelpDesk at x6-8555



The user manual for this document camera is available at:

http://www.calvin.edu/it/services/smartclassrooms/documents/EpsonELPDC05_User_Manual.pdf



Use these items to make the image brighter or darker


A red L-shaped pointer with a dot at the top and a dot at the right end, pointing towards the IRIS control diagram.



Use these items to zoom in or out

A red L-shaped pointer with a dot at the top and a dot at the right end, pointing towards the ZOOM control diagram.

Auto Focus
(AF)



Use this item to have the document camera automatically focus in on the presentation material

A red L-shaped pointer with a dot at the top and a dot at the right end, pointing towards the Auto Focus (AF) icon.